

## **Crossover Washer Preventive Maintenance**

To keep your machine in proper working order, follow the preventive maintenance recommendations provided below.

The maintenance interval should be adjusted according to machine usage.

Leave the loading door open when the machine is not in use.

### **Daily**

Check the door and door lock:

- Open the door and try starting the machine. The machine **MUST NOT START**.
- Close the door, start the machine and try opening the door using reasonable force.
- It **MUST NOT BE POSSIBLE TO OPEN THE DOOR WHILE THE MACHINE IS OPERATING!**
- Check that the door does not leak.
- Clean the door seal, removing any detergent and lint.

Check that there are no indications of leaks behind or around the machine.

Clean out any residue remaining in the detergent dispenser.

Use a soft wash cloth and mild detergent to clean door and plastic panels.

Inspect liquid chemical tubing and connections for leaks. Repair as necessary.

### **Every third month (refer this service to qualified personnel)**

Check the drain pump strainer and remove any accumulated lint and debris.

Inspect the interior of the machine (during an actual wash cycle to ensure that no leaks are noticed) by:

- Turning of the main power switch of the machine.
- Remove the top panel.
- Start a wash program.
- **KEEP CLEAR OF MOVING PARTS WHILE MACHINE IS OPERATING!!**
- Inspect all internal hoses, seals and gaskets for signs of leakage.
- Repair as necessary.
- Stop the machine and disconnect the power. Turn off the water supply and check that the water inlet screens are clear of debris. Dirty screens result in longer fill times, reducing productivity.
- Inspect the drive belt. Adjust the tension or replace as necessary.
- Check that there are no signs of leakage on the floor beneath the machine. Locate and repair any leak.

Contact your local dealer, or Laundrylux Technical Support at 516-371-0700 if you have questions regarding installation, operation, or maintenance of your machine.